

## Tools Needed

- Phillips Screwdriver

**STEP 1**



Locate the two rollers on the bottom of the operable panel. These are enclosed inside of that panel. An adjustment screw on the end of each roller allows you to raise or lower the panel by turning the screw clockwise or counterclockwise.

**STEP 2**



Check the alignment of the door panel and frame by closing the panel. If there is a gap at the top or bottom, adjust the panel up or down to close the gap.

**STEP 3**



Adjust as needed until the door panel is balanced.